



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	50080083R	Guard plug				
2	3	3801068R	Screw				
3	1	50080100R	Complete muffler KAT EURO 2				
4	1	50080059R	Gasket				
5	1	50080112	Labels kit				
6	1	50072028	Gasket set				
7	4	3860095R	Screw				
8	1	3055115	Spark plug				
9	1	50072051	Crankcase assy				
10	1	50080082R	Screw guide				
11	1	026400089A	Tube				
12	1	50070207	Decompressor				
13	2	50080013R	Piston ring Ø45				
14	1	50070117R	Piston pin				
15	2	004900061R	Ring				
16	1	50082014B	Piston assy				
17	1	50070047CR	Gasket				
18	1	097000059A	Spring				
19	1	50070010AR	Manifold				
20	1	50070151A	Tube				
21	1	2318981R	Carburetor HDA-314				
22	1	50080114	Complete cylinder				
23	1	3034012R	Bearing				
24	1	094000005	Bearing				
25	1	50070001R	Crankshaft				
26	2	007201313R	Seal ring				
27	4	3860096	Screw				
28	2	094600042	Plug				
29	1	005000016	Bearing				
30	1	50070039BR	Gasket				
31	2	50070186	Gasket				
32	8	3960074	Screw				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070077	Cable				
2	2	094000097	Screw				
3	2	006000315R	Washer				
4	2	3916004R	Washer				
5	1	094600097AR	Spark plug cap				
6	1	094600169A	Spring				
7	2	50070148	Spacer				
8	1	2501001R	Ignition coil				
9	1	097000064AR	Starter handle				
10	1	50070123R	Starter rope				
11	4	3960092AR	Screw				
12	1	50050073R	Spring				
13	1	50070050A	Starter pulley				
14	1	094500034R	Washer				
15	1	094600041AR	Screw				
16	1	50072011AR	Starter assy				
17	2	004000142	Nut				
18	2	3833080	Washer				
19	2	005000361	Washer				
20	1	50072029	Pawl				
21	1	50260015R	Flywheel				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070095	Guard				
2	1	095000219AR	Spring				
3	1	50010243	Pin				
4	1	50010088AR	Spring				
5	1	3960045	Screw				
6	1	50070124A	Plate				
7	1	3026003	Ring				
8	1	097000146	Lever				
9	1	094500297R	Clutch				
10	1	3960073R	Screw				
11	1	50050125R	Plate				
12	1	50050039R	Brake band				
13	1	006000300	Bushing				
14	1	50070149	Guard				
15	1	50070033	Spike				
16	2	3960098R	Screw				
17	1	50010148R	Nut				
18	1	3960093	Screw				
19	1	50070081	Cover				
20	1	094500029	Spring				
21	1	50070088	Washer				
22	1	3049007	O-ring				
23	1	50070080	Chain tensioner screw				
24	1	50070087AR	Adjuster nut				
25	1	50072027A	Chain tensioner kit				
26	1	50072015AR	Chain cover				
27	1	50070069	Washer				
28	1	50070025R	Worm gear				
29	1	005000165R	Bearing				
30	1	50080023	Chain sprocket .325				
31	1	375100012AR	Washer				
32	1	097000106R	Plug				
33	1	094500046R	Ring				
34	1	094600332R	Bar				
34	1	094600333R	Bar				
35	1	30629530	Efco chain				
35	1	30629512	Efco chain				
36	1	50070110BR	Chain cover				


▲
35



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50070034R	Knob				
2	1	50072031A	Air filter cover				
3	1	50070036R	Air filter standard				
3	1	50070244R	Air filter optional				
4	1	50070056	Gasket				
5	1	50070066	Deflector				
6	3	3960092AR	Screw				
7	1	50070193BR	Cylinder cover				
8	1	50072009R	Cap				
9	1	099900090	O-ring				
10	1	005000347A	Grommet				
11	2	50070067A	Tie rod				
12	1	097000229R	Breather valve				
13	2	50070052AR	Screw				
14	1	50070211	Plate				
15	1	50072010BR	Oil filter				
16	1	094600369R	Guard				
17	1	094600041AR	Screw				
18	5	50050067	Spacer				
19	1	50080068R	Air filter support				
20	1	2317021R	Switch				
21	1	2317013	Guard				
22	1	50070062	Spike				
23	2	3960098R	Screw				
24	1	50070055	Plate				
25	1	50070054	Tube				
26	1	50170051AR	Oil pump				
27	2	3960074	Screw				
28	2	3960057R	Screw				
29	1	50070228R	Lever				
30	5	3860097R	Screw				
31	1	50070114ER	Crankcase assy				
32	3	3933100R	Nut				
33	1	50080076R	Guard				
34	1	50080089R	Guard				
35	1	50072028	Gasket set				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50072009R	Cap				
2	1	099900090	O-ring				
3	3	50070049R	Support				
4	1	3960073R	Screw				
5	3	50070024R	Spring				
6	3	3057005	Washer				
7	2	50010061R	AV-mount				
8	1	50070182	Strap				
9	1	50060039	Tube				
10	1	61110034R	Tube				
11	1	2318817R	Air purge				
12	1	50070260	Throttle kit				
13	1	50050214A	Cover				
14	1	50050046AR	Lever				
15	1	097000028R	Spring				
16	1	50070065BR	Tank assy				
17	3	3960099R	Screw				
18	1	094500577A	Breather valve				
19	1	094500575R	Spring				
20	1	50050071	Breather valve				
21	1	50010218R	Fuel filter				
22	1	50070064	Fuel line				
23	4	094600041AR	Screw				
24	1	3960057R	Screw				
25	1	50070181	Strap				
26	1	3916005R	Washer				
27	1	4098377R	Band				



■ 5 KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	2318106	Cap				
2	1	2318109	Adjust. screw MAX				
3	1	2318984	Adjust. screw MIN				
4	2	2318107	Spring				
5	1	2318673	Repair kit				
6	1	2318981R	Carbuirettor HDA-314				