



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	6	56520107	Screw				
2	1	56520009	Cover				
3	1	56520097	Gasket				
4	1	56520010R	Gasket				
5	1	56520011AR	Muffler				
6	1	3801020	Screw				
7	2	3801059	Screw				
8	7	3819009R	Washer				
9	13	3916006R	Washer				
10	1	61120022	Gasket				
11	2	3801030R	Screw				
12	2	3833073R	Washer				
13	1	3049005R	O-ring				
14	1	56520031A	Knob				
15	2	56520102	Spacer				
16	1	56520098	Plug				
17	1	56522023	Piston assy				
18	1	56522024	Cylinder				
19	2	56520095R	Piston ring				
20	1	3055114	Spark plug				
21	1	56520132	Seal ring				
22	1	56520105	Seal ring				
23	1	094600097AR	Spark plug cap				
24	1	56520129R	Crankcase				
25	1	3960091AR	Screw				
26	8	3918005	Washer				
27	2	56520100	Spacer				
28	1	56520101	Bearing				
29	1	56520096	Gasket				
30	2	56520131R	Bearing				
31	1	56520099	Crankshaft				
32	1	094600169A	Spring				
33	1	56520067AR	Throttle cable				
34	2	3025025	Ring				
35	1	56520063R	Cable				
36	1	56520004	Flywheel				
37	4	3860096	Screw				
38	1	56520122	Grommet				
39	1	56520033	Cap				
40	1	3801010R	Screw				
41	1	3918020R	Washer				
42	1	56520040AR	Plate				
43	1	56520039AR	Shaft joint				
44	1	3027005R	Ring				
45	1	56520038AR	Pulley				
46	1	004000132R	Spring				
47	1	56520124A	Ignition coil				
48	1	56520021R	Gasket				
49	2	3801017R	Screw				
50	1	56520022A	Insulator				
51	1	56520023A	Gasket				
52	1	2318495R	Carburetor WYK-176A				
53	1	56522003AR	Support				
54	1	56520066	Bushing				
55	1	097000064AR	Starter handle				
56	1	56520025R	Air filter				
57	1	56522004A	Filter cover				
58	1	4098073R	Starter rope				
59	2	005000343	Washer				
60	1	3912011R	Nut				
61	4	3801013R	Screw				
62	1	56520008CR	Starter assy				
63	3	3916004R	Washer				
64	1	56520007R	Clutch driver				
65	1	3801003	Screw				
66	1	3028013R	Key				


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
67	1	3916010R	Washer				
69	6	3801028	Screw				
70	1	56522025	Labels kit				
71	1	4161211R	Bush				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56520035A	Cover				
2	1	56520034	Plate				
3	1	56520001B	Half volute				
4	1	56520112	Guard				
5	18	3960091AR	Screw				
6	2	3819006R	Washer				BT6-066-07/09
7	1	56520048DR	Tank				
8	1	56520117B	Half volute				
9	1	56520003A	Impeller				
10	2	56520086A	Harness				
11	1	56520075AR	Padding				
12	4	3055054	Clip				
13	1	56520111	Frame				
14	1	56520070	Support				
15	2	56020136	Anti-vibration springs assy				BT6-066-07/09
16	2	3918005	Washer				
17	2	3801016R	Screw				BT6-066-07/09
18	1	4098377R	Band				
19	1	61070011AR	Breather valve				
20	1	56520051R	Tube				
21	1	50010218R	Fuel filter				
22	1	4161211R	Bush				
23	1	56520049	Tube				
24	1	61070079R	Tank cap				
25	2	3901064	Screw				
26	2	3914003R	Nut				
27	4	3801026	Screw				
28	4	3819009R	Washer				
29	3	56520042R	Cover				BT6-066-07/09
30	1	61070006R	Gasket				
31	1	56520050	Tube				
32	2	365200150A	Clamp				
33	1	56520119A	Guard				
34	1	3980015	Nut				
35	3	56520043	Flange				BT6-066-07/09
36	4	3916006R	Washer				
37	2	3065010A	Hooking spring				
38	1	56520045	Guard				
39	1	50070176	Guard				
40	1	56520127R	Cap				
41	1	56020136	Anti-vibration springs assy				BT6-066-07/09
42	1	56020134R	Bushing				BT6-066-07/09
43	1	3918005	Washer				BT6-066-07/09
44	1	50070024R	Spring				BT6-066-07/09
45	1	3918010R	Washer				BT6-066-07/09
46	1	3833073R	Washer				BT6-066-07/09
47	1	3801016R	Screw				BT6-066-07/09
48	1	50070049R	Support				BT6-066-07/09
49	1	56020135	Flange				BT6-066-07/09
50	1	3960112	Screw				BT6-066-07/09




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56520058R	Tube				
2	1	56520080BR	Tube				
3	3	3960067AR	Screw				
4	1	56520068	Washer				
5	3	56520065	Flange				
6	1	61040053R	Plate				
7	1	61040051	Slide control				
8	1	56520062	Lever				
9	2	3057007	Spring				
10	1	56520059DR	Half grip				
11	2	61040054R	Plate				
12	1	56520081	Spring				
13	1	56520060B	Half grip				
14	1	56520056AR	Tube				
15	1	3049031	Ring				
16	1	56520064	Limiter switch				
17	1	56520061R	Throttle				
18	1	56520110BR	Tube				
19	1	3960061AR	Screw				
20	1	56520047B	Elbow				
21	1	56520057R	Band				
22	1	56520052A	Tube				
23	1	56520053R	Band				
24	1	3960091AR	Screw				
25	1	56520063R	Cable				
26	1	56520067AR	Throttle cable				
27	1	56522009D	Complete handle				
28	1	56522022	Tool kit				



6 Kit riparazione
 Repair kit

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318491	Pump body assy				
2	1	2318703	Washer				
3	2	2318580	Screw				
4	1	2318813	Support				
5	1	2318493	Valve				
6	1	2318674	Repair kit				
7	1	2318571	Cover				
8	1	2318572	Primer pump				
9	4	2318585	Screw				
10	1	2318592	Valve				
11	1	2318189	Ring				
12	1	2318577	Adjuster nut				
13	1	2318969	Primer body				
14	1	2318568	Spring				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	56020017	Plate				
2	1	56020039	Tube				
3	3	56020038	Tube				
4	2	3059008	Band				
5	1	3024010R	Ring				
6	1	56020100	Joint				
7	1	56020101	Pump body				
8	3	3960067AR	Screw				
9	2	3035230R	Bearing				
10	1	3050014	Seal ring				
11	2	56020102	Shaft				
12	1	56020103R	Impeller				
13	1	3049043	O-ring				
14	1	56020105	Cover				
15	1	56020099R	Pompa booster pump				
16	1	56020130B	Support				
17	2	56020021	Pin				
18	2	3618010	Washer				
19	2	3606025	Screw				
20	2	56020019R	Knob				
21	10	3960091AR	Screw				
22	1	56020106	Fittings				
23	4	3049039R	O-ring				
24	1	56020041B	Diaphragm				
25	1	56020113B	Gasket				
26	2	56020150R	Clamp				
27	2	3801017R	Screw				
28	2	3914003R	Nut				
29	1	56020002A	Tank				
30	1	56020006	Filter				
31	1	56020005	Cap				
32	1	56020116A	Gasket				
33	1	56022018B	Complete cap				
34	1	56020004B	Gasket				
35	1	56020040	Cable				
36	3	3960087AR	Screw				
37	5	3059006	Band				
38	1	56020046	Guard				
39	2	56020136	Anti-vibration springs assy				
40	2	56020112R	AV-mount				
41	1	56020134R	Bushing				
42	1	3918005	Washer				
43	1	50070024R	Spring				
44	1	3918010R	Washer				
45	1	3833073R	Washer				
46	1	3801016R	Screw				
47	1	50070049R	Support				
48	2	56020135	Flange				
49	1	3960112	Screw				
50	1	56020136	Anti-vibration springs assy				
51	2	56020110	Harness				
52	1	56020033	Valve				
53	1	3612004	Nut				
54	1	56520031A	Knob				
55	1	56020065	Stud				
56	1	56020035	Rear nozzle				
57	1	56020087AR	Filter				
58	1	56020083	Ulv disc				
59	1	56020036	Front nozzle				
60	1	3015003	Nut				
61	1	3618003	Washer				
62	1	56020075R	Complete diffuser				
63	1	56020085	Filter				
64	2	56020097	Tube				
65	1	3049044	O-ring				
66	1	56020076BR	Cock				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
67	1	56020119C	Conversion kit from BV162 to AM162				