



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318817R	Air purge				
2	1	61200027R	Cylinder cover				
3	2	4191069B	Plate				
4	2	3801065R	Screw				
5	2	3819036R	Washer				
6	1	3916006R	Washer				
7	1	61200061R	Muffler				
8	1	61200063R	Deflector				
9	1	3055115	Spark plug				
10	1	61330095R	Gasket				
11	2	074000405R	Piston ring				
12	2	004900061R	Ring				
13	1	50110047R	Piston pin				
14	1	50120034A	Piston assy Ø40				
15	1	61202022	Complete cylinder				
16	1	50110044R	Thrust bearing				
17	2	50110043AR	Spacer				
18	1	61200001R	Crankshaft				
19	1	61200064R	Stopper				
20	1	61200113AR	Pair half-casings				
21	1	3860096	Screw				
22	2	094000006R	Bearing				
23	1	61200006AR	Gasket				
24	2	094000099R	Seal ring				
25	4	3860095R	Screw				
26	4	3833073R	Washer				
27	2	3023008R	Plug				
28	1	3916005R	Washer				
29	1	3819006R	Grower				
30	1	3801011	Screw				
31	2	3960030	Screw				
32	1	3960032R	Screw				
33	1	61202038R	Gasket set				





Fino a
Till
Jusqu'a
Hasta
Bis




23/01/07
matr. 2047046943



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61200258R	Starter assy				
2	1	61200015R	Starter handle				
3	1	56520087R	Starter rope				
4	6	3801010R	Screw				
5	4	3916005R	Washer				
6	1	004000132R	Spring				
7	1	56520038AR	Pulley				
8	1	3027005R	Ring				
9	1	56520039AR	Shaft joint				
10	1	56520040AR	Plate				
11	1	3918020R	Washer				
12	1	61200012R	Spark plug cap				BT3-071-03/07
13	1	61200062AR	Clutch driver				
14	1	61202039A	Flywheel				BT3-071-03/07
15	1	61200042R	Cable				BT3-071-03/07
16	2	3801013R	Screw				
17	2	3819006R	Grower				
18	2	3912009	Nut				
19	2	3818011A	Washer				
20	1	61202039A	Flywheel				BT3-071-03/07
21	1	61200059R	Adaptor				
22	2	3801016R	Screw				
23	1	61200060R	Adaptor				
24	2	3914003R	Nut				
25	1	4161364	Bushing				
26	1	4161428R	Sleeve				
27	1	3024015	Snap ring				
28	1	61200031AR	Starter case				
29	1	3035042R	Bearing				
30	1	3025022R	Seeger				
31	1	61200032R	Clutch drum				
32	1	4191027FR	Pin				
33	1	4191028R	Spring				
34	1	4191153AR	Clutch				
35	1	61200067R	Spring				BT3-071-03/07
36	1	61250015BR	Ignition coil				BT3-071-03/07
37	1	61250047R	Cable				BT3-071-03/07
38	1	61250014AR	Flywheel				BT3-071-03/07
39	1	61200260	Starter kit assy				
40	2	4191016R	Pawl				
41	1	61252002R	Clutch driver				
42	1	4191018BR	Starter pulley				
43	1	072700089R	Bushing				
44	2	3024007	Ring				
45	2	3064010	Washer				
46	2	4191017A	Spring				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	61200019AR	Gasket				
2	1	61200198	Insulator				
3	2	3801015R	Screw				
4	1	61212062	Complete support				
5	1	61200196AR	Gasket				
6	1	2318765AR	Carburetor WT-869A				
7	1	61200025BR	Air filter				
8	1	61200026R	Cover				
9	1	61200028BR	Complete tank				BT3-072-04/07
10	1	4098377R	Band				
11	1	61200092AR	Tube				
12	1	61200093R	Tube				
13	1	4161211R	Bush				
14	1	61070011AR	Breather valve				
15	1	61250228R	Tube				
16	1	61070079R	Tank cap				
17	1	61070006R	Gasket				
18	1	50010218R	Fuel filter				
19	1	61200057R	Stand				
20	5	3819006R	Grower				BT3-072-04/07
21	5	3918005	Washer				BT3-072-04/07
22	1	3801011	Screw				
23	2	3801014	Screw				
24	1	61200024R	Lever				
25	1	3960087AR	Screw				
26	1	61200023AR	Shutter				
27	1	4120070	Washer				
28	4	61200128R	Spacer				BT3-072-04/07
29	4	3916008R	Washer				BT3-072-04/07
30	4	61200129R	Spring				BT3-072-04/07
31	4	3801016R	Screw				BT3-072-04/07
32	1	61202038R	Gasket set				
33	1	61200091R	Tube				
34	1	61210047R	Guard				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	3914003R	Nut				
2	3	3801015R	Screw				
3	1	4161619R	Band				
4	1	61202023R	Tube Ø26				
5	1	61170075R	Drive shaft				
6	6	3918010R	Washer				
7	4	3801017R	Screw				
8	4	3819006R	Grower				
9	1	61010024R	Clamp				
10	1	61032012R	Handle				
11	1	61040050AR	Lever				
12	1	61040057R	Spring				
13	1	61040052	Pawl				
14	1	61040049	Throttle lever				
15	1	61040056R	Spring				
16	1	61010019	Band				
17	1	3960061AR	Screw				
18	1	61040054	Plate				
19	1	61040053	Plate				
20	1	61040051	Slide control				
21	3	3960067AR	Screw				
22	1	3801011	Screw				
23	1	61012006AR	Handle				
24	1	4161319A	Grip-end				
25	1	61200045R	Throttle cable				
26	1	61200044R	Cable				
27	1	61040132	Bevel gear set				
28	1	61042026R	Guard				
29	1	61040074AR	Screw				
30	1	4100456R	Guard				
31	1	4179089R	Flange				
32	1	3025018R	Ring				
33	1	3024010R	Ring				
34	1	3034008R	Bearing				
35	1	3035230	Bearing				
36	1	3025009	Ring				
37	1	4138311A	Ring				
38	1	61050013R	Gear case				
39	1	61040071R	Cap				
40	1	3901016	Screw				
41	1	3034218	Bearing				
42	1	61040106A	Pin				
43	1	3034012R	Bearing				
44	1	3025022R	Seeger				
45	1	3050018R	Seal ring				
46	1	61040066R	Spacer				
47	1	61040145R	Hub				
48	1	3901008R	Screw				
49	1	61250237A	Set bevel gear Ø26 + insert				BT3-082-03/09
50	1	61250237A	Set bevel gear Ø26 + insert				
51	1	61250054R	Pin				
52	1	61110074R	Guard				
53	1	61110075R	Nut				


Zama mod.C1Q-E12 compl. p.n. 2320051R



16 ● KIT MEMBRANE & GUARNIZIONI
DIAPHRAGM & GASKET SET








15 ■ KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	2318388	Screw				
2	1	2318387	Ring				
3	1	2318872	Shutter				
4	1	2318412	Hooking spring				
5	1	2318689	Shaft				
6	1	2318528	Spring				
7	1	2318696	Screw H				
8	2	2318687	Caps-lock				
9	1	2318697	Screw L				
10	1	2318880	Cover				
11	2	2318522	Screw				
12	2	2320053	Screw				
13	1	2320052	Cover				
14	1	2318876	Screw				
15	1	2318886	Repair kit				
16	1	2318885	Diaphragm+gasket set				
17	1	2318535	Ring				



15 ■ KIT RIPARAZIONE
REPAIR KIT

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50010141	Screw				
2	2	095000164	Ring				
3	1	072700211	Shutter				
4	1	2318211	Pin				
5	1	2318737	Shaft				
6	1	072700347	Spring				
7	1	2318837	Adjust. screw				
8	1	2318893	Screw L				
9	1	074000240	Adjust. screw				
10	1	2318191	Cover				
11	4	035000162	Screw				
12	1	003300202	Screw				
13	1	375100087	Cover				
14	1	003300201	Spindle				
15	1	2318671	Repair kit				
16	1	094600148	Spring				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	-	-	Not available for this product			Sostituita da testina completa codice 63019016 (inserto maschio), 63019018 (inserto femmina); Replaced by complet head p/n 63019016 (male insert), 63019018 (female insert)	
2	2	3960040R	Screw				
3	1	4174278	Plate				
4	4	3802004CR	Screw				
5	1	4174283AR	Skirt w/blade				
6	1	4174275R	Blade				
7	1	61042035BR	Guard				
8	2	4199005AR	Bushing				
9	1	4199008B	Insert (male)				
10	1	4199004	Spring				
11	1	4199042R	Nylon spool Ø3				
12	1	4095673B	Disk				
13	1	4199035BR	Cover				
14	1	61052031	Tool kit				
15	1	4160463AR	Single harness				
16	1	61202020	Labels kit				
17	-	-	Not available for this product			Sostituita da testina completa codice 63019016 (inserto maschio), 63019018 (inserto femmina); Replaced by complet head p/n 63019016 (male insert), 63019018 (female insert)	
18	1	61110076	Insert (female)				
19	1	4199052	Nylon spool				
20	1	4199026A	Cover				
21	1	4199046	Cover				
22	1	63019016	Compl. nylon head Ø3			Inserto maschio; Male insert	
22	1	63019018	Compl. nylon head Ø3			Inserto femmina; Female insert	