



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	3055114	Spark plug				
2	2	50050032	Screw				
3	4	3801047	Screw				
4	2	3960073R	Screw				
5	1	3050022AR	Seal ring				
6	2	50110043AR	Spacer				BT4-085-02/07
7	2	004900061R	Ring				
8	1	50050222	Piston pin				
9	1	094600103	Band				
10	1	50110045R	Crankshaft				BT4-085-02/07
11	2	50060076	Gasket				
12	1	50050010R	Manifold				
13	2	3933100R	Nut				
14	2	094000006R	Bearing				
15	1	50050027A	Muffler				
16	1	074000405R	Piston ring				
17	1	50060027A	Piston assy Ø40				
18	1	50060028B	Cylinder				
19	1	3037013	Bearing				
20	1	3050024AR	Seal ring				
21	1	50050001	Crankshaft				
22	1	50050016AR	Cover				
23	1	50110044R	Thrust bearing				BT4-085-02/07
24	1	50110047R	Piston pin				BT4-085-02/07
25	1	50120034A	Piston assy Ø40				BT4-085-02/07
26	1	50060103	Complete cylinder Ø40				BT4-085-02/07




3
 Kit etichette
 Labels set
 Jeu étiquette
 Juego etiquetas
 Etikettenkit


Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	097000064AR	Starter handle				
2	1	50070123R	Starter rope				
3	1	50060030	Labels kit				
4	1	50050073R	Spring				
5	1	50050017AR	Starter pulley				
6	1	094500034R	Washer				
7	1	50050240R	Flywheel				
8	1	3960057R	Screw				
9	1	50060110	Starter assy				
10	1	3960082BR	Screw				
11	1	006000315R	Washer				
12	1	3916004R	Washer				
13	1	50050081	Cable				
14	1	50060086	Flange				
15	1	50050261	Nut				BT4-083-01/07
16	1	3833080	Washer				
17	1	005000361	Washer				
20	1	50050013AR	Ignition coil				
21	1	50050127	Spring				
22	1	3960075	Screw				
23	1	005000347A	Grommet				
24	1	50050126	Spark plug cap				
25	1	50072029	Pawl				
26	1	50050124	Spacer				
27	1	50050148	Plate				
28	1	50060112	Starter assy				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	3	097000061AR	Screw				
2	3	50050359R	Spring				
3	1	50052045	Throttle kit				
4	1	50050214AR	Cover				
5	1	097000028R	Spring				
6	1	50050123R	Strap				
7	1	50120029R	Fuel tank				
8	2	50052005R	Tank cap				
9	2	3960073R	Screw				
10	2	3049025	O-ring				
11	1	094600450R	Fuel filter				
12	4	094600041AR	Screw				
13	1	3960057R	Screw				
14	1	50050070AR	Tube				
15	1	50050096AR	Lever				
16	2	50010061R	AV-mount				
17	1	3918010R	Washer				
18	1	61110034R	Tube				
19	1	094500575R	Spring				
20	1	094500577A	Breather valve				
21	1	50050071R	Breather valve				
22	3	50050182R	Support				
23	1	50070197A	Knob				
24	1	50050044A	Throttle rod				
25	2	3059017	Band				
26	1	50050119	Plate				
27	1	2318817R	Air purge				
28	1	50060021	Sheath				
29	1	50060039	Tube				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50030372	Bearing				
2	1	50060033A	Chain sprocket .325				
3	1	004000352	Washer				
4	1	094500029	Spring				
5	1	094000129AR	Clutch				
6	1	3960070AR	Screw				
7	1	50050125R	Plate				
8	1	50050039R	Brake band				
9	1	3026003	Ring				
10	1	097000146	Lever				
11	1	50052014AR	Chain cover assy				
12	1	097000106R	Plug				
13	1	50050064R	Pin				
14	2	50010148R	Nut				
15	1	50050040R	Guard				
16	1	50010088AR	Spring				
17	1	50050066	Plug				
18	1	095000219AR	Spring				
19	1	004400285	Washer				
20	1	50060008R	Worm gear .325				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	50052005R	Tank cap				
2	1	3049025	O-ring				
3	2	094600262A	Tie rod				
4	4	50050067	Spacer				
5	1	50052006A	Oil filter				
6	1	097000229R	Breather valve				
7	4	3833073R	Washer				
8	4	3860096	Screw				
9	1	094600369R	Guard				
10	1	094600041AR	Screw				
11	1	50050269B	Starter lever				
12	1	50050133	Chain tensioner kit				
13	1	2318940R	Carburetor WT-561A				
14	1	50050121	Screw guide				
15	1	50050049R	Tube				
16	1	50050084R	Cover				
17	3	3960074	Screw				
18	2	3960057R	Screw				
19	1	50170051AR	Oil pump				
20	1	50060092AR	Crankcase				
21	2	50050052R	Stud				
22	1	3933100R	Nut				
23	1	50050034	Knob				
24	1	2317021R	Switch				
25	1	50050036AR	Air filter				BT1-017-07/07
25	1	50050331R	Air filter optional				BT1-017-07/07
26	1	50050056BR	Gasket				
27	1	50050035C	Support				
28	1	2317013	Guard				
29	1	50062023	Spike				
30	1	50050122R	Guard				


FINO A NOVEMBRE 2004
 TILL NOVEMBER 2004
 BIS NOVEMBER 2004
 HASTA NOVIEMBRE 2004
 JUSQU'A NOVEMBRE 2004

16 ■ KIT RIPARAZIONE
 REPAIR KIT



DA NOVEMBRE 2004
 FROM NOVEMBER 2004
 AB NOVEMBER 2004
 DESDE NOVIEMBRE 2004
 DEPUIS NOVEMBRE 2004

16 ■ KIT RIPARAZIONE
 REPAIR KIT



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	094600148	Spring				
2	1	074000240	Adjust. screw				
3	1	095000141	Shutter				
4	3	003300209	Screw				
5	1	094600208	Spring				
6	1	50050112	Shaft				
7	1	035000165	Spring				
8	1	50050104	Screw L				
9	1	50050105	Screw H				
10	1	093500115	Spring				
11	4	035000162	Screw				
12	1	2318191	Cover				
13	1	003300202	Screw				
14	1	003300201	Spindle				
15	1	50050115	Spring				
16	1	2318671	Repair kit				
17	1	50050111	Lever				
18	1	50050109	Bushing				
19	1	003300036	Fittings				
20	1	50050107	Cover				
21	1	003300197	Screw				
23	1	2318940R	Carburetor WT-561A				
24	1	094600140	Shutter				
25	1	50050117	Screw				
26	1	50050113	Shaft				
27	1	50050110	Bushing				
28	1	50050108	Throttle lever				
29	1	50050121	Screw guide				
37	1	2318944	Screw L				
38	1	2318946	Screw H				
58	1	2318695	Cap				
59	1	2318694	Cap				