


1) Type for: LT3WZ-1508A、LT3WZ-1510A、LT3WZ-1808A、LT3WZ-1810A



S/N	Name	PCS	S/N	Name	PCS
1	Crankcase	1	49	Bolt	8
2	Oil mirror flake	1	50	Valve socket	6
3	Oil mirror	1	51	Valve socket O-ring	6
4	Oil mirror O-ring	1	52	Valve bracket	6
5	Bearing cover O-ring	1	53	Valve spring	6
6	Bearing cover	1	54	Valve patch	6
7	Washer	4	55	Valve seat	6
8	Bolt	4	56	Valve O-ring	6
9	Nameplate	1	57	O-ring	1
10	Oil inlet plug O-ring	1	58	Water inlet guide	1
11	Oil inlet plug	1	59	Inlet filter	1
12	Crankcase cover O-ring	1	60	Water inlet connector	1
13	Crankcase cover	1	61	O-ring	1
14	Bolt + Washer	6	62	Water inlet guide nut	1
15	Oil outlet plug	1	63	O-ring	1
16	Oil outlet plug O-ring	1	64	O-ring	1
17	Flange	1	65	Water outlet guide	1
18	Flange O-ring	1	66	O-ring	1
19	Crankshaft oil seal	1	67	Wimble valve	1
20	Washer	4	68	Wimble valve spring	1
21	Bolt	4	69	O-ring	1
22	Bearing	1	70	O-ring	1
23	Clip	1	71	Water outlet connector	1
24	Crankshaft	1	72	QC connector G1/2	1
25	Bearing	1	73	Chemical injection spring	1
26	Plunger pin	3	74	Chemical injection valve	1
27	Connecting rod	3	75	Chemical injection O-ring	1
28	Plunger	3	76	Chemical injection	1
29	Water proof washer	3	77	O-ring	1
30	Back-ring	3	78	Water outlet guide nut	1
31	O-ring Φ7×2.0	3	79	Adjust valve stem	1
32	Ceramic plunger pipe	3	80	O-ring	1
33	Plunger washer	3	81	Adjust valve	1
34	Plunger nut	3	82	O-ring	1
35	Plunger oil seal	3	83	O-ring	1
36	Water seal seat	3	84	Adjust valve body	1
37	Water seal	3	85	O-ring	1
38	Bracket	3	86	O-ring	1
39	Brass bracket	3	87	Back-ring	1
40	Water seal	3	88	Adjust valve plug	1
41	Water seal underprop	3	89	Adjust valve spring	1
42	O-ring	3	90	Brass washer	1
43	Screw thread plug G3/8	1	91	Adjust valve nut	1
44	O-ring	1	92	Nut	1
45	Screw thread plug G1/2	1	93	Adjust valve screw cap	1
46	O-ring	1	94	Adjust handle	1
47	Cylinder	1	95	Washer	1
48	Washer	8	96	Bolt	1